

Tab up

Connector B Radio Side
Blue Male 20 pin 17 wires

Back

1	2	3	4	5	6	7	8	9	10
11	E	E	E	12	13	14	15	16	17

Front

10	9	8	7	6	5	4	3	2	1
17	16	15	14	13	12	E	E	E	11

Aftermarket Connector B Female 20 pin 13 wire

Back

8	7	6	5	4	3	E	E	2	1
13	E	12	11	10	9	E	E	E	E

9

Front

1	2	E	E	3	4	5	6	7	8
E	E	E	E	9	10	11	12	E	13

1 Blue 7 Orange 13 Black
2 Red 8 Yellow
3 Purple 9 Purple/Black
4 Green 10 Green/Black
5 Gray 11 Brown/Black
6 White 12 White/Black

Radio side Connector L Male 26 pin 15 wire

Back

1	2	E	E	E	3	4	5	6	7	8	9	10
11	12	13	E	E	14	E	E	E	E	E	E	15

Front

10	9	8	7	6	5	4	3	E	E	E	2	1
15	E	E	E	E	E	E	14	E	E	13	12	11

AMP side coming from Radio
20 pin 14 wires

Male Amp side Connector D 20 pin 14 wires

Back

1	2	3	4	5	6	7	8	9	10
11	E	E	12	13	14	E	E	E	E

Front

10	9	8	7	6	5	4	3	2	1
E	E	E	E	14	13	12	E	E	11

Male Amp side Connector E

Back

1	2	5	6	9	10	11
3	4	7	8	12	13	14

Front

11	10	9	6	5	2	1
14	13	12	8	7	4	3